




44.2 Left-hand air cleaner carries the temperature sensor




44.5 Air filter element




54.3 Fuel filter (1), fuel supply rail (2), right-hand (3) and left-hand (4) fuel rails



54.5 Fuel pump



59.1 Fuel cooler



59.14 Fuel injector, showing fuel rail (1), injector clamp nut (2), electrical connector (3) and flexible fuel connecting hose (4)